



#### **OWNER'S MANUAL**

### **220 SNATCHER**

#### **PARTS**

NOTE: MANUAL including SPECIFICATIONS, subject to change without notice.

All ratings specified are based on structural factors only,
not vehicle capacities or capabilities.



Miller Industries Towing Equipment Inc. 8503 Hilltop Drive Ooltewah, Tennessee 37363 Phone (423) 238-4171 • FAX (423) 238-5371

#### LIMITED WARRANTY

MILLER INDUSTRIES TOWING EQUIPMENT INC., hereinafter referred to as MILLER, warrants to the original purchaser that each new MILLER wrecker or other MILLER products will be free from defects in material and workmanship for a period of twelve (12) months from date placed in service, but in no event shall such warranty period exceed twenty-four (24) months from date of manufacture by MILLER. The purchaser must promptly notify MILLER in writing of any failure in material or workmanship. In no event shall MILLER accept such notification later than twenty-four (24) months from date of delivery or twelve (12) months from date placed in service, whichever is earlier.

MILLER's obligation under this warranty, statutory or otherwise, is limited to the repair or replacement at the MILLER factory, or at a point designated by MILLER, of such part or parts as shall appear upon inspection by MILLER to be defective in material or workmanship. New or remanufactured parts will be used for any replacement at MILLER's option. This warranty is not transferable. This warranty does not obligate MILLER to bear the cost of labor or transportation charges in connection with the repair or replacement of any parts found to be defective, nor shall it apply to a product upon which repairs or alterations have been made unless authorized by MILLER.

EXCEPT AS EXPRESSLY SET FORTH IN THIS WARRANTY, MILLER MAKES NO OTHER WARRANTY, EXPRESS OR IMPLIED, AND HEREBY DISCLAIMS ALL OTHER WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. MILLER shall in no event be liable for claimed downtime, claimed loss of profits or goodwill, or any other special, incidental, indirect, or consequential damages concerning or relating to any product or parts, whether based on negligence, strict liability, breach of contract, breach of warranty, misrepresentation or any other legal theory, regardless of whether the loss resulted from any general or particular requirement which MILLER knew or had reason to know about at the time of sale.

MILLER MAKES NO WARRANTY, EXPRESS OR IMPLIED, AS TO THE FINISHED PRODUCTS MANUFACTURED OR SUPPLIED BY ANOTHER MANUFACTURER AND SUPPLIED BY MILLER TO PURCHASER, including, but not limited to, any vehicle to which a MILLER product may be affixed or any accessories or wire rope, and MILLER EXPRESSLY DISCLAIMS ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE AS TO SUCH EQUIPMENT OR PRODUCTS. This language shall in no way affect or diminish the rights of the purchaser to rely on such warranties as are extended by such manufacturers or suppliers. MILLER shall, to the extent permitted under applicable law, pass on to the purchaser such manufacturer's or seller's warranty.

MILLER, whose policy is one of continuous improvement, reserves the right to improve its products through changes in design or materials as it may deem desirable without being obligated to incorporate such changes in products previously sold. This warranty is not intended to cover or include the following items, which are set forth by way of example and not limitation:

- A. Normal deterioration of trim, paint, lettering, and appearance items due to wear or exposure to weather, road conditions, road treatments, etc.
- B. Any damage or defect due to accident, misuse, abuse, improper or unauthorized repairs, failure to provide reasonable and necessary maintenance, or uses for which the equipment was not designed or intended.
- C. Alterations or modifications that affect performance, operation or reliability.
- D. Normal maintenance parts including, but not limited to, wear pads, bushings, wire rope, mud flaps, fenderettes, light bulbs, hydraulic oil, filters, and tow sling belts.

IT IS EXPRESSLY UNDERSTOOD THAT MILLER MAKES NO IMPLIED WARRANTY THAT MILLER PRODUCTS SHALL BE FIT FOR THE PURPOSE OF LIFTING OR MOVING PEOPLE OR FOR ANY OTHER IMPROPER USE.



Miller Industries Towing Equipment Inc. 8503 Hilltop Drive Ooltewah, Tennessee 37363 Telephone (423) 238-4171

-

**SERIAL NUMBER** 

### **OWNER, USER AND OPERATOR:**

We appreciate your choice of our towing and recovery unit for your application. Our number one priority is user safety which is best achieved by our joint efforts. We feel that you can make a major contribution to safety if you, as the equipment owner and operator:

- 1. Comply with Federal, State, and Local Regulations.
- 2. Read, Understand, and Follow the Instructions in this Manual.
- 3. Use Good, Safe Work Practices in a Common Sense Way.
- 4. Only have Authorized and Trained Personnel performing maintenance on the Towing and Recovery Unit.

#### **TABLE OF CONTENTS**

It is assumed by the manufacturer that the Owner/Operator has a thorough knowledge of the accepted and lawful retrieval and towing methods as dictated by his city, county or state. The manufacturer rejects any liability claim that may result from the incorrect or unlawful application of its equipment.

#### **Section I - PARTS**

SUBFRAME ASSEMBLY	I-2 & I-3
BOOM ASSEMBLY	I-4 & I-5
WHEEL LIFT ASSEMBLY	I-6 & I-7
CROSSBAR ASSEMBLY	I-8 & I-9
BOOM HYDRAULICS	I-10 & I-11
WHEEL LIFT HYDRAULICS	I-12 & I-13
CLAW HYDRAULICS	I-14 & I-15

#### **Section VI - PARTS**

This Section is provided by the manufacturer for the purpose of ordering any component part of the **Holmes 220 Snatcher** that may be required when part replacement is necessary. Be certain to use only original equipment replacement parts for warranty purposes as well as for keeping your unit in its original state and optimum operating capacities.


When ordering replacement or spare parts be sure to provide the following information to the manufacturer's **Parts Department**.

- 1. Manual Number & Date of Publication
- 2. Manual Page Number
- 3. Page Title
- 4. Reference Number of Part Desired
- 5. Part Number
- 6. Part Description
- 7. Quantity of Part Desired

Providing this information will help ensure that the correct parts will be delivered to you in an expedient manner without delay. Should additional information be required for repair or replacement of certain components, contact your Wrecker Manufacturer Authorized Representative.

The Manufacturer reserves the right, without notice or obligation, to improve or modify their products, which may change the specifications, models and feature availability.

Section I - PARTS (cont'd)
SUBFRAME ASSEMBLY




### Section I - PARTS (cont'd) SUBFRAME ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22	0300113 0300134 03001895 0400070 0400126 0400367 0400392 0400451 0400452 0400482 0400487 0719519 0719520 9041353 25318004 25318008 25318000 810710000 HD0230	GREASE FITTING, 1/4-28 STRAIGHT HOSE CLAMP, 1" INSULATED GREASE FITTING, 1/8 NPT STRAIGHT 1/4-20 X 1 HHCS GR5.ZP 3/8-16 X 1 HHCS GR5.ZP 1/4-20 NYLOCK HEX NUT ZP 3/8-16 NYLOCK HEX NUT ZP 1/4 FLAT WASHER ZP 1/4 FLAT WASHER ZP 3/8 FLAT WASHER ZP 3/8 HELICAL LOCK WASHER ZP 3/8 HELICAL LOCK WASHER ZP 5/16 HELICAL LOCK WASHER ZP SHIM - BOOM PIVOT (.0747 THICK) SHIM- BOOM PIVOT (.1196 THK) 7/16-20 UNF X 3/4 LG. HHCS SUBFRAME WELD'T HPU COVER WELDMENT BOOM PIVOT PIN WELDMENT HPU ASSEMBLY PIN WELDMENT LIFT CYLINDER 3/8-16 X 2 HHCS GR5 ZP	2 2 2 4 1 1 2 2 6 4 2 1 1 1 1 1 1 2 2

F-3

# Section I - PARTS (cont'd) BOOM ASSEMBLY




I-4

# Section I - PARTS (cont'd) BOOM ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26	0301895 0303521 0306688 0400070 0400082 0400126 0400343 0400367 0400410 0400451 0400452 0400480 0400492 0708519 0718102 9041402 9053713 9056125 25317081 25318001 25318001 810730000	GREASE FITTING, 1/8 NPT STRAIGHT SPRING, HOSE TENSIONER TIMBREN SPRING 1/4-20 X 1.125 EYE BOLT 3/8-16 X 1 HHCS GR.5, ZP 1/2-13 X 2 HHCS GR.8, ZP 1/4-20 NYLOCK HEX NUT ZP 1/4-20 NYLOCK HEX NUT ZP NUT, 1/2"-13 HEX JAM ZP 1/4 FLAT WASHER ZP 1/4 HELICAL LOCK WASHER ZP 3/8 FLAT WASHER ZP 3/8 HELICAL LOCK WASHER ZP 1/2 FLAT WASHER ZP 1/2 HELICAL LOCK WASHER ZP 1/2 TLAT WASHER ZP 1/2 HELICAL LOCK WASHER ZP 1/2 HELICAL LOCK WASHER ZP 1/2 HELICAL LOCK WASHER ZP 1/2 HALICAL LOCK WASHER ZP 1/2 HELICAL LOCK WASHER ZP 1/2 HALICAL LOCK WASHER ZP 1/2 HALICAL LOCK WASHER ZP 1/2 HELICAL LOCK WASHER ZP 1/2 HALICAL LOCK WASHER ZP 1/2 HELICAL LOCK WASHER ZP 1/2 HELICAL LOCK WASHER ZP 1/2 HALICAL LOCK WASHER ZP 1/4 HELICAL LOCK	1 1 1 1 2 1 1 2 1 1 1 2 1 1 3 2 2 1 1 1 3 2 2 1 1 1 1

### Section I - PARTS (cont'd) WHEEL LIFT BOOM ASSEMBLY




## Section I - PARTS (cont'd) WHEEL LIFT BOOM ASSEMBLY

TEM	
	ITEM PAR
2 3012-794004 PLATE - UL PAD CAGE 3 0301397 GREASE FITTING, 90 DEG 4 0306819 PAD, SLIDE 5 0400066 114-20 X 3/4 HHCS GR.5, 2P 6 0400121 3/8-16NC X 3/4 HHCS GR.5, 2P 7 0400126 3/8-16 X 1 HHCS GR.5, 2P 8 0400133 3/8-16 X 1 HHCS GR.5, 2P 10 0400139 SCREW, 3/8'-16 X 1-1/2'' HEX SKT SET 11 0400204 1/2-13X3/4 SKT HD SET 12 0400343 1/2-13 X 2 HHCS GR.8, 2P 13 0400349 SCREW, 3/8'-16 X 3/4" FL HD SKT 14 0400367 1/4-20 NYLOCK HEX NUT ZP 15 0400392 3/8-16 NYLOCK HEX NUT ZP 16 0400398 3/8-16 NYLOCK HEX NUT ZP 17 0400410 NUT, 1/2''-13 HEX JAM ZP 18 0400416 1/2-13 NYLOCK HEX NUT GR.8, ZP 19 0400482 3/8 HELICAL LOCK WASHER ZP 20 0400497 1/2 FLAT WASHER GR.8, YZ PLATED 21 0400505 5/8 FLAT WASHER SAE 22 0400606 5/8 X 1-1/4 SHOULDER BOLT 23 0717674 SHIM - PAD SPACER 24 0718216 SHAFT-INNER TUBE CYLINDER 25 0718217 PLATE - XBAR POSITIONING 26 9048166 TUBE CHAMP, DOUBLE 27 25317020 BEARING - HOSE 30 25318003 INNER STINGER BOOM WELDT 31 25318003 INNER STINGER BOOM WELDT 31 25318003 INNER STINGER BOOM WELDT 32 25318001 PIN SETION PAD 34 810040004 SHEAVE, SMALL GROOVED 1 NYLATRON PAD 37 0310639 CYLINDER 2.5 BORE X 1.13	2   301 3   00 4   00 5   00 6   00 7   00 8   9   00 110   00 111   12   13 13   14   00 15   16   17 16   00 17   00 18   00 20   00 21   00 22   23 24   00 22   25 26   29 27   2½ 28   22 29   22 30   22 31   22 31   22 32   32 33   34   81 35   81 36   89

L-7

## Section I - PARTS (cont'd) CROSSBAR ASSEMBLY



## Section I - PARTS (cont'd) CROSSBAR ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17	0300113 0303844 0400349 0400428 0400546 0400590 0400667 0401006 0710092 0711385 0806978 0806979 0806981 0806981 0806982 E300002 HD0106	GREASE FITTING, 1/4-28 STRAIGHT CYLINDER, SWING L-ARM SCREW, 3/8"-16 X 3/4" FL HD SKT 5/8-11 FLEXLOC THIN HIGH COTTER PIN, 1/8" X 1-1/4" CLEVIS PIN 3/8-16X1/2 FLT SOC HD THREAD LOCK 3/8"-16 X 1" FL HD SKT CAP SCREW THRUST WASHER PIN - CYLINDER (L-ARM END) LEFT L-ARM WLDT RIGHT L-ARM WLDT CROSSBAR WELDMENT PIN PIVOT WLDT-XBAR PIN L ARM PIVOT BEARING - CLAW PIVOT 1/4 X 1-3/4 ROLL PIN ZP	3 2 2 2 2 2 2 2 1 1 1 2 2 2 2


## Section I - PARTS (cont'd) BOOM HYDRAULICS

I-10

## Section I - PARTS (cont'd) BOOM HYDRAULICS

ITEM	PART NUMBER	DESCRIPTION	QTY
1 2 3 4 4	9301522 0310311 25319009 810710000	CONNECTOR 6MJ-6MB HOSE ASSY - 72" LG HPU ASSEMBLY LIFT CYLINDER	9 2 1 1 1


Section I - PARTS (cont'd)
WHEEL LIFT HYDRAULICS



### Section I - PARTS (cont'd) WHEEL LIFT HYDRAULICS

ITEM	PART NUMBER	DESCRIPTION	QTY
1 2 3 4 5 6 7 8	0301522 0301921 0302922 0307042 0307460 25319009 810730000 0310639	CONNECTOR 6MJ-6MB HOSE ASSEMBLY, 128" LG HOSE ASSEMBLY, 170" LG CONNECTOR, (6MJ-6MBR-3/64) FITTING, ELBOW, 6MJ-6MB90L HPU ASSEMBLY CYLINDER HYDRAULIC FOLD CYLINDER 2.5 BORE X 1.13	9 2 2 1 1 1 1

## Section I - PARTS (cont'd) CLAW HYDRAULICS



I-14

## Section I - PARTS (cont'd) CLAW HYDRAULICS

ITEM	PART NUMBER	DESCRIPTION	QTY
1 2 3 4 5 6 7 8 9 10 11 11 12 13 14	0301522 0301696 0302531 0303864 0303862 0303866 0308867 0400487 0718102 25313002 25319009 HC1291	CONNECTOR 6MJ-6MB ELBOW, 6MJ-6FJX90 HOSE ASSY - 75" LG CYLINDER, SWING L-ARM HOSE ASSEMBLY, 17" HOSE ASSEMBLY, 112" LG PLUG - 1/4 SAE O-RING BULKHEAD UNION (4MJ-4BLKHD W/NUT) 7/16 HELICAL LOCK WASHER ZP BAR HOSE TENSIONER HOSE ASSEMBLY - 110" LG HPU ASSEMBLY CONNECTOR, 4MJ-4MB STR	7 2 2 2 1 1 1 2 2 2 1 1 1 6

